

# partstore >

## Parts & Accessories Catalog 2007

Sony · Toshiba · Sharp · RCA  
Pioneer · Kenwood · Hitachi  
Dell · Nokia · Motorola · GE  
Samsung · Yamaha · Frigidaire  
Sylvania · Whirlpool · Ericsson  
Apple · Maytag · JVC · More...



**866-902-7278**

**America's largest source for replacement parts & accessories**

Consumer Electronics, Cameras & Camcorders, Cellular, Computers, and Appliances  
America's largest source for replacement parts and accessories

An alphabetical listing of our principal part offerings. We carry consumer and service/repair parts for all major brands.

## 2 A B C

### AC adapters for cellular phones, laptops and electronics

Air cleaner parts and accessories

Air conditioner parts and accessories

Amplifier (home) parts and accessories

Answering machine parts and accessories

Antennas for cellular phones and electronics

### Appliance parts

Audio and video cables for home electronics and laptops

Auto adapters for cellular phones, laptops and electronics

Bake elements for appliances

Batteries for camcorders and portable DVD players

### Batteries for cellular phones

Batteries for cordless phones

Batteries for laptops

### Battery chargers for cellular phones, laptops, electronics

Belts for appliances, VCRs, turntables

Broiler elements for appliances

Burner Modules (electric) for appliances

Burner Modules (gas) for appliances

Burner Modules (halogen) for appliances

Burner caps for appliances

Burner grates for appliances

CD player parts and accessories

CD-ROM parts and accessories

CD/RW drives for computers

Cabinet parts for appliances

Camcorder parts and accessories

Camera parts and accessories

Car Stereo parts and accessories

### Cellular phone parts and accessories

### Chargers for cellular phones and PDAs

### Computer parts and accessories

Cooktop parts and accessories

Cordless phone batteries

## 3 D E F

DVD drives for computers

DVD player parts and accessories

DVD-ROM parts and accessories

Dehumidifier parts and accessories

Dials for appliances and home electronics

Digital camera batteries

### Digital camera parts and accessories

Dishwasher parts and accessories

Disk drives for computers

Doors for appliances

Drawers for appliances

Drip pans for appliances

Dryer heating elements for appliances

Dryer parts and accessories

Duct and vent parts for appliances

Electric shaver parts and accessories

Electrical parts for electronics and computers

Eye cups for camcorders

Faceplates for car stereos

Faceplates for cellular phones

Fans for appliances, computers, and electronics

Fax machine parts and accessories

Feeder trays for office equipment

Filters (HEPA) for appliances

Filters (charcoal) for appliances

Filters (electrostatic) for appliances

Filters (grease) for appliances

Filters (lint) for appliances

Filters (water) for appliances

Flatbed Scanner parts and accessories

Floppy drives for computers

Freezer parts and accessories

Front panels for appliances

## 4 G H I

Garbage disposal parts and accessories

Graphics cards for computers


Grates and Grilles for appliances

HDTV parts and accessories

Handles for appliances

Headphones for home and portable electronics

Headsets for cellular phones



Heat sinks for computers  
Heater parts and accessories  
Home theater system parts and accessories  
Hoses for appliances  
Humidifier parts and accessories  
Ink cartridges for printers

**5**  
**JKL**

Keyboards for computers  
Knobs and buttons for home electronics  
**Knobs for appliances**  
Lamps for appliances and projectors  
Laptop parts and accessories  
Laserdisc player parts and accessories  
LCD screens for camcorders and laptops  
Lens caps for camcorders and cameras  
Lens filters for camcorders and cameras  
Lights for appliances  
Lights for camcorders and cameras  
Lint Screens for appliances

**6**  
**MNO**

MP3 player parts and accessories  
Magazines for disc players  
Manuals (instruction) for microwaves, computers, and electronics  
Manuals (service) for microwaves, computers, and electronics  
**Memory and memory modules for computers**  
**Memory sticks for home and portable electronics**  
Mice for computers  
Microcassette recorder parts and accessories  
Microphones for home and portable electronics  
Microwave oven parts and accessories  
Minidisc player parts and accessories  
Modem parts and accessories  
Modems for computers  
Motherboards for computers  
Mounting parts for electronics, computers, and appliances  
Nozzles for appliances  
Optical Eye (Laser) for home electronics  
Oven parts and accessories

**7**  
**PRS**

PDA parts and accessories  
Panels (front) for appliances  
Paper trays for office equipment  
Power adapters for cellular phones, laptops and electronics  
Power cords for computers and home electronics  
Power supplies for computers  
Printer parts and accessories  
Racks for dishwashers, refrigerators, stoves, microwaves  
Receiver parts and accessories


Refrigerator parts and accessories  
**Remote controls for home electronics and car radios**  
**Restore CDs for computers**  
Scanner parts and accessories  
Screen protectors for home electronics  
Service parts for electronics, computers, cellular, and appliances  
Sewing machine parts and accessories  
Shelves for appliances  
Shredder parts and accessories  
Silverware baskets for appliances  
Sound cards for computers  
Speaker cables for home electronics  
Speaker parts and accessories  
Speaker parts for home electronics  
Speakers for computers and home electronics  
Spouts and sprayers for appliances  
Stereo parts and accessories  
Storage pans for appliances  
Stove parts and accessories  
Stylus for PDAs  
System boards for computers and home electronics

**8**  
**TUV**

Tape player parts and accessories  
Telephone parts and accessories  
Television parts and accessories  
Temperature controllers for appliances  
Toner cartridges for printers  
Touchpads for laptops  
Touchpads for microwaves  
Trackballs for computers  
Trays and tray supports for microwaves  
Trays for refrigerators  
Trim and trim kits for appliances  
Turntable parts and accessories  
Turntable trays for microwaves  
VCR parts and accessories  
Vacuum cleaner parts and accessories  
Video cards for computers  
Viewfinders for camcorders and cameras


**9**  
**WXY**

Washer parts and accessories  
Water filtration parts and accessories  
Water heater parts and accessories  
Wiring for electronics  
Wiring harnesses for cars



Call and get your parts now.

**1 (866) 902-PART**



# partstore > Parts & Accessories 2007

PartStore solves the parts problem in these key verticals:

---

## Home Electronics

- Remote controls
- Projector bulbs
- Headphones
- Memory sticks
- Screen protectors
- Power cords

## Cameras & Camcorders

- Batteries
- Lenses
- Memory sticks
- Adapters

## Computers

- Laptop batteries
- Keyboards, Mice, Modems
- Memory and memory modules
- Speakers
- Toner cartridges

## Cellular Phones

- Batteries
- Antennas
- Car adapters
- Chargers
- Faceplates
- Headsets

## Appliances

- Bake and broiler elements
- Burner caps, grates, modules
- Ducts, doors and drawers
- Filters (HEPA, water, more)
- Knobs, handles and hoses
- Lint screens and vents
- Temperature controllers
- Replacement bulbs
- Trim and cosmetic parts
- Turntables and trays

*And More....*

---

We also carry Service Manuals and Instruction Manuals

An exploded view diagram of a mechanical assembly, likely a motor or a similar device. The diagram shows various components such as a housing, a motor core, a fan, and various fasteners like screws and bolts. The components are arranged in a way that shows their relative positions and how they fit together. The background is white, and the lines are thin and black.

## About the Company

PartStore meets all of your replacement part and accessory needs with one stop shopping for all the products in your home. We are America's largest source of electronic, appliance, computer and wireless parts and accessories. Whenever you need a part, PartStore is there to help you find the one that will fit your product perfectly.

Whether you need an original remote for your TV to catch the game in picture in picture or need to replace the broken knob on your range, PartStore will help you find the right part quickly and conveniently. Orders can be placed online at PartStore or with the help of a parts expert, toll-free at 1-866-902-PART (7278).

PartStore is committed to helping you extend the life of your products by delivering the parts that will restore your products back to their original condition. PartStore offers superior customer service through live personal assistance, real-time order tracking, easy returns and the largest selection of parts available anywhere.

PartStore is the one place you can rely on for all the hard to find parts you need.

**partstore** >

**CORPORATE ACCOUNTS**

Toll-free: 866-902-7278

Fax: 212-201-0303

[corpaccounts@partstore.com](mailto:corpaccounts@partstore.com)